

REPLACEMENT PARTS

Ref.	No.	Part No.	Description
	1	902171	INTAKE
	2	901-11-023-1476	CARRIAGE HD SCREW
	3	1343390	LOCK WASHER
	4	902-01-010-1300	HEX NUT
	5	902169	SUPPORT
	7	1346844	UPPER SUPPORT
	9	898959	HANDLE ASSY
	10	1346845	CLAMP
	11	1346846	LOWER SUPPORT
	13	1346847	HANDLE COVER
	14	1346850	MOTOR ASSY
	15	902167	GASKET
	15A	1348463	SWITCH HOUSING
	15B	1348465	CLAMP
	15C	n 1346563	CAPACITOR (30UF)
	15D	901-06-121-7383	SCREW-PAN HD
	15E	1320187	SCREW-PAN HD
	15F	1343759	120V SWITCH, INCL.: REF. 15G
		438-01-017-0141	OPTIONAL 240V SWITCH, INCL.: REF. 15G
	15G	1343758	KEY
	15H	1348466	POWER CORD
	16	902165	DUST BAG
	17	901-01-060-0606	HEX HD SCREW
	19	902166	OUTLET
	20	902168	GASKET
	21	902170	BLOWER HOUSING
	22	904-01-010-1604	FLAT WASHER
	24	901-01-060-0607	HEX HD SCREW
	25	n 911360	IMPELLER
	28	903016	COVER
	29	1310547	PAN HD SCREW
	30	1346521	CAP
	31	1342476	CLAMP
	32	50-194	4 IN X 10 FT HOSE
	35	903018	MOTOR BASE
	37	1350307	HEX HD SCREW
	40	903019	BASE
	41	1350291	HEX NUT
	42	1350288	LOCK WASHER
	43	903020	CASTER
	44	902737	ROTATION LABEL
	45	902781	WARNING LABEL
	46	902713	WARNING LABEL BLADE
	47	905836	NAME PLATE
	48	902172	HARDWARE PACK

STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta Machinery strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Centers for service/repairs. Any product that is presented to a Delta Authorized Service Centers for repairs which contains missing or damaged standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair.

This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department or through your service outlet.